



SHIBUYA

Home entertainment 3.2M.




CONNECT SYSTEM










1





2





3






M3.5x13mm.



1



Use these holes




2









Use these holes





M3.5x20mm.






M3.5x20mm.



HARDWARE

-BODY SET



x 48




(#19)

x 40




(#15)

x 8



x 114



x 78



x 32



x 8




11mm.


x 32




x 1




x 22




x 4



x 8



x 36



x 2



x 32




x 8



M4x16mm.

x 392




M5x70mm.

x 22




M3.5x20mm.

x 48




M4x20mm.

x 12




M3.5x25mm.

x 24




M4x30mm.

x 66



M4x50mm.

x 42




M4x25mm.

x 12




M3.5x13mm.

x 4



M4x20mm.

x 4




M4x35mm.

x 6




M4x16mm.

x 16




x 2



x 1


-DRAWER SET



x 4



x 24




x 40



x 20

-DOOR SET



x 8




x 48



x 4

-LAMP SET




x 20/20



5x3/4"mm.

x 5



x 1




x 1




M4x16mm.


x 4



x 1







x 2



x 2


L = BROWN
N = BLUE
? = GREEN - YELLOW




ASSEMBLY

-BODY SET


1.




2.




3.




4.




5.




6.




7.




8.




9.




10.




11.




12.




15.





16.




13.




14.




17.




18.




19.




20.




21.




22.




23.




24.




25.




26.



27.




28.







LEFT สวิตช์ไฟ (Light Switch)




สวิตช์ไฟ (Light Switch) **RIGHT**




29. RIGHT




29. LEFT




30.




31.




32.




33.









34.




35.



36.




37.




38.

ASSEMBLY


-DRAWER SET




39.




40.



41.



42.



43.

