


EXTREME

TV cabinet 180 cm.



CONNECT SYSTEM

1

3

2

(Connecting bolts)



WHEN FITTING CAMS
 ENSURE STARTING POSITION IS CORRECT
 BEFORE YOU INSERT CONNECTING BOLT
 TURN CLOCKWISE UNTIL SECURE

✓				✗
	CORRECT	WRONG		

M4x16mm.


DOOR PANEL

M4x20mm.




HARDWARE

-BODY SET




x 16



19mm.

x 16




#8x35

x 30



x 12



x 4



x 8




x 8



M4x20mm.

x 8




M4x50mm.

x 10




x 1




M4x30mm.


x 2



x 2



x 2



M5x70mm.

x 2




x 2



M4x16mm.

x 4

-DOOR SET



x 2




M4x16mm.

x 8


ASSEMBLY

-BODY SET



1.




2.




3.




4.



5.



6.



7.

